



- A. All dimensions are in inches
- B. Shown dimensions are field taken, to be verified before installation.
- C. All piping areas are measured to outside of farthest pipe, including insulation.
- D. Piping does not interfere with removing of scale tray
- E. Piping dimension can be changed to accommodate new equipment.